





**Connect your TV:** Choose **1** of the following three options to connect your TV to your Satellite/Cable Box.



If your satellite or cable box has:



**OR**



**OR**



Connect to your TV using:

**Digital HDTV  
HDMI**

**OR**

**Analog HDTV  
Component**

**OR**

**NON-HDTV  
AV Component**

## Optional Components



**Enhance your VIZIO Experience.**

When it comes to components and accessories, don't settle for less than VIZIO. We offer a full line of products specifically designed to accentuate your VW26L. To learn more about how you can enhance your VIZIO experience, call 888-849-4623 or visit [www.VIZIO.com](http://www.VIZIO.com).

### VIZIO High-Definition Certified Cables

Our VIZIO Certified HD cables carry the same standards of excellence as all our VIZIO products.

Available in: DVI, HDMI and Component in lengths of 2, 5, and 10 meters.



### VIZIO Certified Mounts





## Program your TV:

Programming your VW26L is a simple **TWO STEP** process. All you need is your Remote Control.

**1**

Connect your Signal Source to the **DTV/TV** connection.



**Please Note:**

• Be sure the batteries in your remote are inserted correctly.

For advanced setups, refer to chapter 3 of your VW26L User Manual.

### Program your Cable/Satellite Box Remote


Consult your Cable or Satellite Owner's Manual to determine if you need a 3-, 4-, or 5-digit code.

If your Cable or Satellite Box requires:

- 3-digits, please use "627" (This code usually works with DISHNetwork)
- 4-digits, please use "1758" or "0178"
- 5-digits, please use "11758" or "10178" (These codes usually work for DIRECTV)

**2**

## TV Tuner Setup



### On your Remote Control...

- 1 Turn on the TV, the Initial Setup screen should appear. If this screen does not appear see User Manual Chapter 3 for TV Tuner Setup.
- 2 Select Language; English, Français, Español.
- 3 Press **▲** or **▼** once to select Cable or Antenna. Select Cable if you are using cable from the wall or Air if you are using an antenna.
- 4 Press **▶** to continue to the next screen.
- 5 Press **OK** on remote to scan for channels. Scanning for available channels could take several minutes.
- 6 Once scanning is finished, programming is complete.
- 7 For more detailed information see Chapter 3 of your User Manual.

